



AQUA MINI
COUNTERTOP DISHWASHER



There are some decisions in life that we wish we had made differently. While we can easily adapt and change a few to rig their ultimate outcome in our favour, there are some we simply can't! Changing the layout of an already set kitchen is just one of those things unless you plan on undertaking a renovation. So, what happens if there is a sudden need to include a new appliance to your set kitchen but you have no space available to do so? When it comes to appliances, features such as adaptability in terms of size, unmatched functionality and efficiency are fast becoming crucial.

Häfele introduces the Aqua Mini Dishwasher to its Premium Range of Appliances, an appliance that doesn't require you to make any change to your existing kitchen while providing you with the operations and versatility of a standard high-end dishwasher. The new model is not only a compact freestanding variant but also fits on your kitchen countertop with ease. Ideal for a family of 4 members, the new Aqua Mini Dishwasher can clean up to **75 utensils* in one wash** and comes equipped with **Active Clean Technology which kills 99.99% germs** at a high temperature wash.


Its **dedicated wash programs** can be set to clean different types of utensils depending on the degree of soiling – from a highly soiled kadhai to a delicate wine glass, there is nothing Aqua Mini cannot clean, including itself! The self-cleaning program takes care of the dishwasher once it is done washing the utensil load for the day. The **intuitive digital interface** helps keep track of the time remaining for the wash cycle to complete and showcases details of the ongoing program.

At **49 dBA**, Aqua Mini works silently while you go about completing other tasks in peace. With an **energy rating of A++** and 25% less electricity and water consumption**, this technologically laden dishwasher is 'the' go-to product for any contemporary kitchen. Use Häfele's Range of Dishwasher Additives with the Aqua Mini Countertop Dishwasher to get clean, germ-free dishes after every wash!


* 8 place settings (8 sets of dining utensils and crockeries) and 1 set of serving utensils

** The electricity consumption is lesser than one unit for a full washing cycle in some modes

FEATURES



Compact Size: The Aqua Mini dishwasher is compact, occupying minimal area on your kitchen countertop and can be discreetly stationed in a corner near the sink or placed in a cabinet below the countertop. The versatility it brings in terms of placement, also makes it a convenient retrofit solution for existing kitchens. Equipped with simple and easy-to-use controls, this dishwasher is the perfect companion to your daily washing chores.



Digital Display: Working with Aqua Mini is a breeze owing to its advanced digital display that enables you to check the current program/ function selection and the time remaining for the dish washing cycle to end. With a single touch, any possible function can be achieved thus making it easy to operate and communicate with.




Active Clean Technology: The Aqua Mini Dishwasher comes equipped with an Active Clean Technology in which a combination of high temperature (70 °C) and high pressure (45 L/ min) wash and rinse cycles, directed via the twin spray arms, cover every nook and corner of the dishwasher, providing 99.99% germ-free and clean dishes after every wash cycle.




Capacity: Although compact, the Aqua Mini dishwasher comes with 8 place settings* which allow you to stack up to 75 utensils (approximately) in one go. This comfortably takes care of the everyday washing requirements of a small to medium household. For ease of organization and efficiency while cleaning, this dishwasher comes with a dedicated space for cutlery and separate racks for cups, saucers, bowls, glasses, etc.,. An example of the type and number of utensils that can be stacked into each basket is shown below.

* 8-place settings accommodate 8 sets of dining utensils and crockeries, and 1 set of serving utensils



Upper Basket

No.	Type	Quantity
1	Cups	8
2	Saucers	6
3	Medium serving bowl	1
4	Cutlery in the cutlery rack	



Lower Basket

No.	Type	Quantity
5	Big oval plate	1
6	Glasses	8
7	Large serving bowl	3
8	Dessert dishes	8
9	Dinner plates	8
10	Soup plates	8
11	Large tray	1

Cutlery rack



Stainless Steel Drums: Dishwashers with wash cycles that run at a high temperature for longer periods of time need the internal drum to be of a higher-grade material that can sustain such conditions. Hybrid drums that are generally available in the market get easily worn out within a short period of time due to intensive usage. The Aqua Mini Dishwasher consists of an internal drum made of 100% Stainless Steel since this material performs well in both hot and cold temperatures promising exceptional durability. Stainless Steel is also food safe and hence is protected when exposed to grease, oil and acids present in the food/ spices.

FEATURES



Quiet Technology: The advanced dishwasher motor in Aqua Mini is designed to give you a quieter dishwashing experience. With a maximum noise level of 49 dBA, you can enjoy a peaceful time in your kitchen while the dishes are being quietly washed by the dishwasher.




Soft Touch Shelves: Aqua Mini takes care of your dishes by cradling them with its nylon-coated soft touch shelves that are designed to provide a firm yet gentle hold. You can rest assured now that there will be no scratching or abrasion of any kind while loading, washing and unloading of your crockery and glass. The coating also makes the shelves easy to clean and prevents accumulation of any water residue.




Efficient Fan Assisted Drying: The highly effective integrated drying cycle in the Aqua Mini Dishwasher ensures that there is no residual moisture on the utensils. The fan assisted drying gets activated once the final rinse cycle concludes.



Green Technology: With an A++ Energy rating, this machine utilizes 25% less electricity and water and is also quieter compared to other dishwashers on the market.




Delayed Start Program: Let your dishwasher work around your time! Whether you want to accumulate all your dishes to wash at once or want freshly rinsed and dried dishes just prior to your meals, the delayed start program in the Aqua Mini Dishwasher lets you select or delay the washing time by 3/6/9 hours as needed.



Dishwasher Tablet: The tablet dispensing option in Aqua Mini prevents the hassle of adding multiple additives separately replacing them with just one tablet which is a combination of detergent, salt and rinse-aid. Just insert one tablet in the dishwasher detergent compartment and start the desired program (refer to the Dishwasher Additives section on page no. 6 for more information about this)

Note:

- In case of glassware or plastic, it is recommended to load extra rinse-aid separately to aid the drying process and receive that extra shine on your glassware
- In case the water hardness level in your area is very high, it is recommended to use salt to soften the water for an effective wash cycle



Effective Drainage: The draining system in the Aqua Mini dishwasher drains out any excess water that might get collected due to food residue clogged in the outlet pipe. It also releases the clogged residue with a water flow rate of 13 L/ min and maintains the health of your plumbing system and dishwasher.

FEATURES



The size of the dishwasher although compact can easily accommodate large utensils and cutlery alike



The twin spin spray arms make sure water and detergent reaches every small corner of the dishwasher cleaning all the grime and dirt from every utensil



The Stainless Steel drum increases the durability and efficiency of the dishwasher



Easily dispensable tablets can be used for a quick and effective washing process

HAFELE'S RANGE OF DISHWASHER ADDITIVES

While our dishwashers look out for you and ease your daily chores, they too need a little something that ensures their smooth functionality and helps them perform at their maximum potential. To this effect, Häfele introduces its new range of Dishwasher Additives which when used along with the dishwasher helps you achieve clean and sparkling bright utensils and glassware with every wash.

The New Range of Häfele Additives consists of Dishwasher Detergent, Rinse-aid, Dishwasher Salt, 5-in-1 Dishwashing Power Tablet and Descaling Agent. Use these products along with the Aqua Mini Dishwasher to get the best washing results every time!



Clean and Shine Dishwasher Detergent
For sparkling dishes
 Quantity: 1 kg



Power and Shine Rinse-aid
100% spotless, sparkling and dry dishes in every wash
 Quantity: 500 ml



Water Softening Dishwasher Salt
Dishwasher performance at its optimum
 Quantity: 1 kg

Article No: 532.84.938 Dishwasher Cleaning Kit consists of: 3 packs of 1 kg Dishwasher Detergent, 3 packs of 500 ml Rinse Aid and 3 packs of 1 kg Dishwasher Salt



5-in-1 Dishwasher Power Tablet
Only one tablet and you are done
 Article No: 532.84.668
 Quantity: 30 tablets
 MOQ: 10 packs



Dishwasher Descaling Agent
 Article No: 532.84.669
 Quantity: 100 grams
 MOQ: 10 packs

PROGRAMS AND FUNCTIONS



1 PROGRAMS



Intensive Clean: This is a high temperature washing and rinsing program, intended for tough stains on extremely greased and soiled cooking pans and dishes.

Pre-wash (50 °C) → Wash (65 °C) → 3 x Rinse (65 °C) → Dry

Water Consumption: **12.5 L**; Power Consumption: **1.25 kWh**; Time of Wash: **160 mins**



Regular: The Regular cleaning program is for everyday washing of dishes with low to medium soiling levels that don't require intensive, high temperature washing.

Pre-wash (50 °C) → Wash (60 °C) → 2 x Rinse (68 °C) → Dry

Water Consumption: **12.5 L**; Power Consumption: **1.05 kWh**; Time of Wash: **150 mins**



Eco: This special wash program is designed to give you 100% clean and germ-free dishes with minimal water and electricity consumption.

Pre-wash → Wash (45 °C) → Rinse (65 °C) → Dry

Water Consumption: **8 L**; Power Consumption: **0.72 kWh**; Time of Wash: **185 mins**



Glass: Delicate glassware and crystalware must be treated with the utmost caution and washed separately. This mode is especially designed for all your beautiful wine glasses and crystal tumblers that need a mild temperature and lower spray pressure with a good dose of rinse-aid to keep their sheen intact.

Pre-wash (30 °C) → Wash (45 °C) → 2 x Rinse (60 °C) → Dry

Water Consumption: **10.5 L**; Power Consumption: **0.7 kWh**; Time of Wash: **95 mins**



90 mins: To achieve a thorough cleaning of medium to highly soiled utensils within less time, use the 90 minutes program! With a slightly higher temperature than other modes, this cleaning mode shortens the time needed for effective and germ-free washing.

Wash (65 °C) → 2 x Rinse (68 °C) → Dry

Water Consumption: **11 L**; Power Consumption: **1.15 kWh**; Time of Wash: **90 mins**



Rapid: The Rapid program is a quick program intended for lightly soiled dishes and a medium dishwasher capacity. Totally effective for a smaller number of utensils, this program reduces the washing time tremendously.

Wash (45 °C) → 2 x Rinse (55 °C)

Water Consumption: **7 L**; Power Consumption: **0.52 kWh**; Time of Wash: **35 mins**

PROGRAMS AND FUNCTIONS



Self Clean: With Aqua Mini's self clean mode, you don't need to trouble yourself with manual cleaning anymore. This self-cleaning program delivers effective cleaning and sterilization of the dishwasher for its proper hygiene and maintenance. Run this program with only the detergent (18 grams recommended) to clean any leftover dirt or grime inside the dishwasher.

Wash (70 °C) → 2 x Rinse (65 °C) → Dry

Water Consumption: **7 L**; Power Consumption: **0.8 kWh**; Time of Wash: **50 mins**

2 PROGRAM SELECTOR

This button is used to switch between the different programs listed above with each press in a consecutive pattern starting from Intensive Clean, Regular, Eco, Glass, 90 mins, Rapid and Self Clean.

3 DIGITAL LED DISPLAY

The Digital LED Display shows the selected program - P1 (Intensive Clean), P2 (Regular), P3 (Eco), P4 (Glass), P5 (90 mins), P6 (Rapid) or P7 (Self Clean), washing time left in the selected cycle and the duration of delayed time (if selected) in the delayed start program.

4 DELAYED START

Based on your convenience, you can select when to start a particular washing program. With every press of this button, the delayed time i.e. the number of hours after which you would want to start your dishwashing cycle, toggles circularly between 3 → 6 → 9 hours.

5 START/PAUSE

After loading the dishwasher and setting the program and/or delayed start functions, commence the cycle with the Start button. You can pause the cycle with a further press of this button incase you need to add an extra dish/utensil. The steps to pause a cycle are:

- Press the pause button
- Wait for 5 seconds and open the door
- Add the extra dish/ utensil and close the door
- Press the start button and wait for 10 seconds for the cycle to begin

6 WARNING INDICATORS

The two warning indicators for Rinse Aid and Salt (from left to right), if lit let you know when the dishwasher is running low on rinse aid and salt respectively and needs to be refilled.

PRODUCT SPECIFICATIONS

Article No.: 538.21.300

Model: Freestanding

Finish: Matte Silver

Capacity: 8 place settings* (approximately 75 utensils)

Display: Digital

Energy Efficiency Class: A++

Drying Efficiency Class: A

Noise level: 49 dBA

Programs: Intensive Clean, Regular, Eco, Glass, 90 mins, Rapid, Self Clean

Water Consumption: 8 L


Energy Consumption: 0.72 kWh (in Eco Mode full load wash)

Maximum Power Rating: 1380-1620 W

Rated Voltage/ Frequency: 220-240V/ 50Hz

Water Pressure (flow pressure) at 0.04-1.0 MPa = 0.4-10 bar


Dimensions (W × D × H): 550 × 500 × 590 mm




* 8-place settings accommodate 8 sets of dining utensils and crockeries, and 1 set of serving utensils

INSTALLATION

INSTALLATION TYPE A: DRAINPIPE DIRECT CONNECTION TO MAIN PIPE



INSTALLATION TYPE B: DRAINPIPE CONNECTION THROUGH THE SINK



1. Place the unit over your kitchen counter
2. Attach the source of water supply to the inlet
3. For Installation Type A: Insert the drain hose/pipe (min. diameter of 40 mm) into the main draining pipe of the sink system. This is a permanent connection where the dishwasher can't be moved.
4. For Installation Type B: Let the drain hose/pipe (min. diameter of 40 mm) run into the sink, making sure to avoid bending or crimping it. This is useful when the kitchen has already been constructed as the drain pipe can be retracted from the sink and kept aside after use.
5. For Installation Type B, the free end of the hose must not be immersed in water (in the sink) to avoid back flow of water. Similarly for Installation Type A, backflow of water can occur if the main drain pipe is clogged.

**Mumbai Design Centre:**

Haji Moosa Patrawala Ind.(SOBO)
Estate, Near Famous Studio,
Mahalaxmi (West), Mumbai - 400 011.
Tel.: 022 6264 7100.

Mumbai Design Centre:

#2 Filix Building, Opp. Asian Paints,
L.B.S. Marg, Bhandup (West),
Mumbai - 400 078.
Tel.: 022 2596 9660/
2596 9787/2594 7305

New Delhi Office & Design Centre:

D-89 , 1st Floor, Okhla Phase-I,
New Delhi - 110 020.
Tel.: 011-66574999 .
Fax: 011-41605482.

Bangalore Office & Design Centre:

Incubex Nestavera Spaces Pvt Ltd,
No:13, Langford Place, Langford Road,
Shanti Nagar, Bangalore - 560 025.
Tel.: 080 4132 6116.
Fax: 080 4132 6226.

Bangalore Hafele Appliances Gallery:

No. 2/1, Shiv Manor, Langford Road,
Shantinagar, Bangalore - 560027
Tel.: 080 - 4142 6336

Hyderabad Office & Design Centre:

SJR Building - # 1-57/89/1 & 1-57/89/2
Opp Allahabad Bank, Gachibowli,
Hyderabad – 500032
Tel.: 040 29557578 / 040 29557588

Kolkata Design Centre:

PS PACE, Premises No. 1/1A,
Mahendra Roy Lane, Topsia,
Kolkata - 700 046.
Tel.: 033 40086814 / 033 40089268
Fax: 033 24988020.

Kolkata Office:

Office No. 1001, PS Continental,
10th Floor, 83/2/1 Topsia Road,
Near Vishwakarma Building.
South Kolkata - 700046
Tel: 033-2285 0104 /
033-2285 0105 / 033-2285 0106

Chennai Office & Design Centre:

1st Floor No.24, College Road,
Nungambakkam, Chennai 600 006.
Tel.: 044 - 4215 1542
Fax: 044 2446 0922.

Pune Design Centre:

Showroom No. 2, Ground floor,
F P no. 403, A/2, ICC Trade tower,
Senapati Bapat Marg,
Shivaji Nagar, Pune -411016
Tel.: 020 2563 3301
Fax: 020 2563 3302

Pune Office:

Office No. 12, Vastushree Complex,
Survey No.587, Near Hyde Park,
Gultekdi, Market Yard, Pune - 411 037.
Tel.: 020 2426 6264
Fax: 020 2426 6274.

Ahmedabad Office:

Hafele India Pvt. Ltd., Office No. 302,
3rd Floor, Shangrila Arcade,
Near Shyamal Cross Road, Satellite,
Ahmedabad - 380015.
Tel.: +91 79695 55505 / 8866220505.

Cochin Office

Jomer Symphony, Fifth floor, 48/1744
C34, Chalikkavattom, North
Ponnuranni, Vyttila, Cochin- 682010

Sri Lanka:**Hafele Office and Design Centre:**

52, Nandana Gardens
(On Duplication Road), Colombo 04.
Tel: +94 112 500 501.
Fax: 0094 112 500 553.

Hafele Design Centre:

448, Galle Road, Rawathawatta,
Moratuwa, Sri Lanka.
Tel.: +94 112 644 600.

Hafele Boutique:

747A, Sirimawo Bandaranayaka
Mawatha, Mulgampola,
Kandy, Sri Lanka.
Tel.: +94 812 223 338.

Bangladesh**Bangladesh Office:**

2nd Floor, House - 181, Road - 2,
Mohakhali DOHS, Dhaka - 1206.
Tel.: 01844018431/ 01844018432/
01844018433/ 01844018437.

Bangladesh Design Center:

House - 106, Road - 12,
Block - E, Banani, Dhaka - 1213
Phone - 02-48810380-81

Nepal:

Monika Home Decor
Kathmandu Plaza, Kamalddhi,
Kathmandu, Nepal
Tel.: 00 9851 030 556 /
00 977 9818496082 / 9851030556

Bhutan:**SMART HOMES**

Gr Floor, Druk Building (Opp Helipad)
Babesa -Thimpu Expressway, Thimpu
Tel.: +975-2-333419
Mobile: +975-77277615, 17839717,
77114228,1760063,17669840

HAFELE

Hafele India Private Limited

Office No. 3, Building "A", BETA, I Think
Techno Campus, Off J.V.L.R, Opp. Kanjurmarg
East, Mumbai – 400 042.

Phone: 022 6142 6100 | **Fax:** 022 6702 0531.

New Delhi | Kolkata | Cochin | Chennai |
Hyderabad | Bangalore | Mumbai | Pune |
Ahmedabad | Srilanka | Bangladesh | Nepal |
Bhutan | Maldives

Toll Free Customer Care No.:1800 266 6667
Customer Care WhatsApp No.: +91 9769111122
SMS HAFELE to 56070
info@hafeleindia.com
customercare@hafeleindia.com

